


CURB INLET PROTECTION

City of Angola - Engineering Department

Created: June 4, 2021

Updated: November 4, 2024

Scale: NTS



Notes:

1. Place curb type sediment barriers on gently sloping street segments, where water can pond and allow sediment to separate from runoff.
2. Sandbags of either burlap or woven 'geotextile' fabric, are filled with gravel, layered and packed tightly.
3. Leave one sandbag gap in the top row to provide a spillway for overflow.
4. Inspect barriers and remove sediment after each storm event. Sediment and gravel must be removed from the traveled way immediately.
5. Please reference the Indiana Storm Water Quality Manual for additional specifications.


CURB INLET PROTECTION

City of Angola - Engineering Department

Created: June 4, 2021

Updated: November 4, 2024

Scale: NTS



Notes:

1. Place the curb type sediment barriers on gently sloping street segments, where water can pond and allow sediment to separate from runoff.
2. Sandbags of either burlap or woven 'geotextile' fabric, are filled with gravel layered and packed tightly.
- 3.
4. Please reference the Indiana Storm Water Quality Manual for additional specifications.